



# Smart tag usage guide — Kiilto Pro Hygimon

The staff's anonymous smart tags can distinguish different workgroups while all unidentified persons are categorized as guests. **(1) Take a transponder**, please note that **if the color coding is in use select the correct color equate your workgroup**; in this case follow the instructions given to you regarding the color groups.

If color codes are in use, it is possible to differentiate between different groups in data analysis. Once you've selected the correct transponder just **(2) pin it into your clothing on the front side** and after this Kiilto Pro Hygimon is ready-to-use!

## USE HAND DISINFECTANTS AS USUAL

**(3) Disinfect your hands** during your work shift as usual. The transponders measure and record the data automatically and anonymously.

After the shift the transponder is returned to the transponder box. Please **(4) disinfect the transponder before return** with a disinfection wipe like Kiilto Pro Easydes Wipe.

